



ALL PARTS ORDERS MUST BE FAXED OR MAILED. NO PHONE ORDERS WILL BE ACCEPTED.

Part#	Description	Cost
670	39mm Female Axle	
631	42mm Female Axle	
632	13mm Male Axle Screw	
675	Rocker Inserts	
608B3	Bearing - ABEC-3	
BA6292WH	Wheel-62mm WHT	

Part#	Description	Cost
715	Self Centering Spacer	
676W	Grnd Plate - WHT	
676B	Grnd Block - BLK	
677	Power Strap Assy.	
3202	Top Strap/Lever	
3302	Top Clip	

1. Check the axle screws on each wheel. The male and female should be tightened firmly prior to each use.

1. Prüfen sie die schrauben aller rollen, schraube und mutter vor gebrauch gut festdrehen.

1. Sur chaque roue, vérifiez les vis de l'essieu. Les vis males et femelles doivent être serrées fermement avant l'utilisation des patins.

1. Cheque los tornillos de cada rueda, macho y hembra de los tornillos deberan apretarse antes de cada uso.